

INSTALLATION INSTRUCTIONS

SAFE BOX HANDLING NOTES – PLEASE READ FIRST



To Open: 1. Depress bottom latch with a slotted screwdriver and lid will pop out. 2. Pull top of lid straight out from housing without lifting up. 3. Once entirely pulled out, lift lid and it will remain in open position until closed.
To Close: 1. Push lid down without latching bottom. 2. Push in top hinges until it snaps into place. 3. Close bottom until it latches. 4. Optional screw provided to more permanently secure lid to housing.

Mounting Instructions:




Step 1 – Drill 15/16” hole in desired location in duct. Ensure that sensor is mounted so that air flows through the hole in the sensor probe.

Step 2 – Align opening in mounting flange with hole in duct and attach mounting flange to duct using self-tapping screws.



Step 3 - Insert sensor probe in mounting flange and push until sensor snaps into place. Wire through provided bottom or side access points. Additional snap-in conduit adapters available if necessary.



Wiring Instructions

Terminal	Function
POW +	24V Power Supply
POW -	Ground Power Supply
VOC +	VOC Signal (0-10V)
VOC -	VOC Ground
RH +	RH Signal (0-10V)
RH -	RH Ground

Step 1 – Terminate control wires in quick connects as indicated in the table above.

Step 2 – Power on control.